



NSAI
Standards

Irish Standard
I.S. EN ISO 20884:2019&A1:2021

Petroleum products - Determination of sulfur content of automotive fuels - Wavelength-dispersive X-ray fluorescence spectrometry (ISO 20884:2019)

I.S. EN ISO 20884:2019&A1:2021

Incorporating amendments/corrigenda/National Annexes issued since publication:

EN ISO 20884:2019/A1:2021

The National Standards Authority of Ireland (NSAI) produces the following categories of formal documents:

I.S. xxx: Irish Standard — national specification based on the consensus of an expert panel and subject to public consultation.

S.R. xxx: Standard Recommendation — recommendation based on the consensus of an expert panel and subject to public consultation.

SWiFT xxx: A rapidly developed recommendatory document based on the consensus of the participants of an NSAI workshop.

This document replaces/revises/consolidates the NSAI adoption of the document(s) indicated on the CEN/CENELEC cover/Foreword and the following National document(s):

NOTE: The date of any NSAI previous adoption may not match the date of its original CEN/CENELEC document.

This document is based on:

EN ISO 20884:2019

Published:

2019-10-02

*This document was published
under the authority of the NSAI
and comes into effect on:*

2021-10-31

ICS number:

75.080

75.160.30

NOTE: If blank see CEN/CENELEC cover page

NSAI
1 Swift Square,
Northwood, Santry
Dublin 9

T +353 1 807 3800
F +353 1 807 3838
E standards@nsai.ie
W NSAI.ie

Sales:
T +353 1 857 6730
F +353 1 857 6729
W standards.ie

Údarás um Chaighdeáin Náisiúnta na hÉireann

National Foreword

I.S. EN ISO 20884:2019&A1:2021 is the adopted Irish version of the European Document EN ISO 20884:2019, Petroleum products - Determination of sulfur content of automotive fuels - Wavelength-dispersive X-ray fluorescence spectrometry (ISO 20884:2019)

This document does not purport to include all the necessary provisions of a contract. Users are responsible for its correct application.

For relationships with other publications refer to the NSAI web store.

Compliance with this document does not of itself confer immunity from legal obligations.

In line with international standards practice the decimal point is shown as a comma (,) throughout this document.

This page is intentionally left blank

EUROPEAN STANDARD
NORME EUROPÉENNE
EUROPÄISCHE NORM

EN ISO 20884:2019/A1

October 2021

ICS 75.080; 75.160.30

English Version

**Petroleum products - Determination of sulfur content of
automotive fuels - Wavelength-dispersive X-ray
fluorescence spectrometry - Amendment 1: Addition of the
SSD detector to the Monochromatic excitation part of
Table 1 (ISO 20884:2019/Amd 1:2021)**

Produits pétroliers - Détermination de la teneur en
soufre des carburants pour automobiles -
Spectrométrie de fluorescence de rayons X dispersive
en longueur d'onde - Amendement 1: Ajout du
détecteur SSD à la partie Excitation monochromatique
du Tableau 1 (ISO 20884:2019/Amd 1:2021)

Mineralölerzeugnisse - Bestimmung des
Schwefelgehaltes in Kraftstoffen -
Wellenlängendispersive Röntgenfluoreszenz-
Spektrometrie - Änderung 1: Hinzufügen des SSD-
Detektors zur Spalte Monochromatische Anregung von
Tabelle 1 (ISO 20884:2019/Amd 1:2021)

This amendment A1 modifies the European Standard EN ISO 20884:2019; it was approved by CEN on 22 June 2021.

CEN members are bound to comply with the CEN/CENELEC Internal Regulations which stipulate the conditions for inclusion of this amendment into the relevant national standard without any alteration. Up-to-date lists and bibliographical references concerning such national standards may be obtained on application to the CEN-CENELEC Management Centre or to any CEN member.

This amendment exists in three official versions (English, French, German). A version in any other language made by translation under the responsibility of a CEN member into its own language and notified to the CEN-CENELEC Management Centre has the same status as the official versions.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Republic of North Macedonia, Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION
COMITÉ EUROPÉEN DE NORMALISATION
EUROPÄISCHES KOMITEE FÜR NORMUNG

CEN-CENELEC Management Centre: Rue de la Science 23, B-1040 Brussels

EN ISO 20884:2019/A1:2021 (E)

Contents	Page
European foreword.....	3

European foreword

This document (EN ISO 20884:2019/A1:2021) has been prepared by Technical Committee ISO/TC 28 "Petroleum and related products, fuels and lubricants from natural or synthetic sources" in collaboration with Technical Committee CEN/TC 19 "Gaseous and liquid fuels, lubricants and related products of petroleum, synthetic and biological origin" the secretariat of which is held by NEN.

This European Standard shall be given the status of a national standard, either by publication of an identical text or by endorsement, at the latest by April 2022, and conflicting national standards shall be withdrawn at the latest by April 2022.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CEN shall not be held responsible for identifying any or all such patent rights.

Any feedback and questions on this document should be directed to the users' national standards body/national committee. A complete listing of these bodies can be found on the CEN website.

According to the CEN-CENELEC Internal Regulations, the national standards organizations of the following countries are bound to implement this European Standard: Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Republic of North Macedonia, Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and the United Kingdom.

Endorsement notice

The text of ISO 20884:2019/Amd 1:2021 has been approved by CEN as EN ISO 20884:2019/A1:2021 without any modification.

This page is intentionally left blank

INTERNATIONAL STANDARD

**ISO
20884**

Third edition
2019-08

Petroleum products — Determination of sulfur content of automotive fuels — Wavelength-dispersive X-ray fluorescence spectrometry

*Produits pétroliers — Détermination de la teneur en soufre des
carburants pour automobiles — Spectrométrie de fluorescence de
rayons X dispersive en longueur d'onde*



Reference number
ISO 20884:2019(E)

© ISO 2019

ISO 20884:2019(E)



COPYRIGHT PROTECTED DOCUMENT

© ISO 2019

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Fax: +41 22 749 09 47
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland

Contents

Page

Foreword	iv
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Principle	2
5 Reagents	2
6 Apparatus	2
7 Sampling	3
8 Calibration solutions	3
8.1 Blank solution.....	3
8.2 Stock solution.....	3
8.3 Calibration solutions.....	3
8.4 Storage and stability of the calibration solutions.....	4
9 Settings	4
9.1 Measuring parameters.....	4
9.2 Optimization.....	4
9.3 Performance check of the spectrometer.....	4
10 Calibration	5
10.1 General.....	5
10.2 Calibration solutions.....	5
10.3 Calibration curves.....	5
10.4 Checking.....	6
11 Procedure	6
11.1 Samples with sulfur contents between 5 mg/kg and 60 mg/kg.....	6
11.2 Samples with sulfur contents between 60 mg/kg and 500 mg/kg.....	6
12 Expression of results	6
13 Precision	7
13.1 General.....	7
13.2 Repeatability, <i>r</i>	7
13.3 Reproducibility, <i>R</i>	7
14 Test report	7
Annex A (informative) Good practices	8
Bibliography	9

ISO 20884:2019(E)

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing Documents is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT), see www.iso.org/iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 28, *Petroleum and related products, fuels and lubricants from natural or synthetic sources*.

This third edition cancels and replaces the second edition (ISO 20884:2011), which has been technically revised. The main changes compared to the previous edition are as follows:

- extension of the scope to include hydrotreated vegetable oil (HVO) and the synthetic fuel “gas to liquid” (GTL);
- inclusion of specific procedural steps for instruments utilizing monochromatic excitation.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

Petroleum products — Determination of sulfur content of automotive fuels — Wavelength-dispersive X-ray fluorescence spectrometry

WARNING — The use of this document can involve hazardous materials, operations and equipment. This document does not purport to address all of the safety problems associated with its use. It is the responsibility of users of this document to take appropriate measures to ensure the safety and health of personnel prior to application of the document, and fulfil other applicable requirements for this purpose.

1 Scope

This document specifies a wavelength-dispersive X-ray fluorescence (WDXRF) test method for the determination of the sulfur content of liquid, homogeneous automotive fuels from 5 mg/kg to 500 mg/kg, which have a maximum oxygen content of 3,7 % (*m/m*). This product range covers:

- diesel fuels containing up to about 30 % (*V/V*) fatty acid methyl esters (FAME),
- motor gasolines containing up to about 10 % (*V/V*) ethanol,
- synthetic fuels such as hydrotreated vegetable oil (HVO) and gas to liquid (GTL) having sulfur contents in the range of 5 mg/kg to 45 mg/kg.

Products with higher oxygen content show significant matrix effects, e.g. pure FAME used as biodiesel, nevertheless, pure FAME can be analysed when the corresponding procedures are followed (see 5.3 and 8.1).

Other products can be analysed with this test method, though precision data for products other than those mentioned have not been established for this document.

NOTE 1 Sulfur contents higher than 500 mg/kg can be determined after sample dilution, however, the precision was not established for diluted samples.

NOTE 2 For the purposes of this document, “% (*m/m*)” and “% (*V/V*)” are used to represent the mass fraction, *w*, and the volume fraction, *φ*, of a material respectively.

2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 3170, *Petroleum liquids — Manual sampling*

ISO 3171, *Petroleum liquids — Automatic pipeline sampling*

3 Terms and definitions

No terms and definitions are listed in this document.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at <https://www.iso.org/obp>
- IEC Electropedia: available at <http://www.electropedia.org/>

ISO 20884:2019(E)

4 Principle

The sample under analysis is exposed in a sample cell to the primary radiation of an X-ray tube. The count rates of the S K-L_{2,3} X-ray fluorescence and, where required, the count rate of the background radiation are measured. The sulfur content of the sample is determined from a calibration curve defined for the relevant measuring range.

NOTE The IUPAC X-ray line notation (S K-L_{2,3}) is used in this document; the corresponding Siegbahn X-ray line notation (S K α or S K $\alpha_{1,2}$) is being phased out.

5 Reagents

5.1 Dibutylsulfide, of nominal sulfur content 21,92 % (m/m), or **dibutyldisulfide**, of nominal sulfur content 35,95 % (m/m), used as a calibrating substance for sulfur.

Care should be taken due to volatility (see [Annex A](#) for further guidance).

NOTE Certified reference materials (CRM) produced in accordance with ISO 17034[3] are suitable alternatives.

5.2 White oil (paraffinum perliquidum), for use as a blank solution, of high purity grade, with a sulfur content of less than 1 mg/kg. Check the blank solution prior to use with the spectrometer ([6.1](#)). A signal for sulfur shall not be detectable.

5.3 Methyl oleate, for use as a blank solution when pure FAME is analysed, with a sulfur content of less than 1 mg/kg. Check the blank solution prior to use with the spectrometer ([6.1](#)). A signal for sulfur shall not be detectable (i.e. the intensity shall be lower than the intensity equivalent to 1 mg/kg). Other oxygen-containing and sulfur-free blank solutions, such as octanol, can also be used.

6 Apparatus

6.1 Wavelength-dispersive X-ray fluorescence spectrometer, with the capability for measuring the count rates of the S K-L_{2,3} X-ray fluorescence radiation and the background radiation.

Due to the inherently low background radiation produced by instruments utilizing monochromatic radiation for excitation, it is not mandatory to measure the background radiation when this type of instrument is used. The minimum requirements for the spectrometer are given in [Table 1](#).

6.2 Analytical balance, capable of weighing to the nearest 0,1 mg.

Table 1 — Spectrometer requirements

Component	Polychromatic excitation	Monochromatic excitation
Anode	Rhodium, scandium or chromium	Rhodium, scandium, chromium or titanium
Voltage ^a	No less than 30 kV	No less than 30 kV
Current ^a	No less than 50 mA	No less than 0,1 mA
^a Lower-power polychromatic systems may be used, provided they have been validated to meet the precision values specified in Clause 13 . ^b In instruments using vacuum, the sample is not exposed directly to the vacuum of the optical path, but is separated by a secondary window. ^c Polyester film is the preferred choice as samples of very high aromatic content may dissolve polycarbonate film. There are possibly trace amounts of silicon, calcium and sulfur in some types of film. However, the effects should be cancelled out when samples and standards are analysed using the same batch of film. It is important that samples, standards and blanks be measured using the same batch of film to avoid bias. Other sample window materials with the same or better absorptivity, purity and stability can also be used.		

Table 1 (continued)

Component	Polychromatic excitation	Monochromatic excitation
Collimator or optic	Coarse collimator	Monochromator
Analysing crystal	Germanium, pentaerythrite or graphite	Germanium, pentaerythrite or graphite
Optical path ^b	Vacuum or helium	Vacuum or helium
Sample cup window ^c	Polyester film, 4 µm maximum thickness	Polyester film, 4 µm maximum thickness
Detector	Proportional counter with pulse-height analyser	Proportional counter with single channel analyser
Wavelengths	S K-L _{2,3} at 0,537 3 nm Background radiation at 0,545 nm	S K-L _{2,3} at 0,537 3 nm

^a Lower-power polychromatic systems may be used, provided they have been validated to meet the precision values specified in [Clause 13](#).

^b In instruments using vacuum, the sample is not exposed directly to the vacuum of the optical path, but is separated by a secondary window.

^c Polyester film is the preferred choice as samples of very high aromatic content may dissolve polycarbonate film. There are possibly trace amounts of silicon, calcium and sulfur in some types of film. However, the effects should be cancelled out when samples and standards are analysed using the same batch of film. It is important that samples, standards and blanks be measured using the same batch of film to avoid bias. Other sample window materials with the same or better absorptivity, purity and stability can also be used.

7 Sampling

Unless otherwise specified, samples shall be taken by the procedures described in ISO 3170 or ISO 3171.

8 Calibration solutions

8.1 Blank solution

Use white oil ([5.2](#)) as a blank solution.

If pure FAME is under analysis, use a blank solution in accordance with [5.3](#) to minimize potential matrix effects.

8.2 Stock solution

Weigh a quantity of the required calibrating substance ([5.1](#)) to the nearest 0,1 mg, and dilute with blank solution ([5.2](#) or [5.3](#), as appropriate) at room temperature so that a stock solution with an accurately known sulfur content (to the nearest 1 mg/kg) of approximately 1 000 mg/kg is obtained.

Care should be taken due to volatility of the calibrating substance (see [Annex A](#) for further guidance).

8.3 Calibration solutions

Weigh an appropriate quantity of the stock solution ([8.2](#)) to the nearest 0,1 mg into bottles and dilute with blank solution ([5.2](#) or [5.3](#), as appropriate) so that standard solutions with sulfur contents in accordance with [Tables 2](#) and [3](#) are obtained by stirring at room temperature. The sulfur contents in the calibration solutions are indicated in milligrams per kilogram, rounded to the nearest 0,1 mg/kg.

Table 2 — Calibration solutions — Low sulfur range

Number	Sulfur content mg/kg
Blank solution 0	0,0
2.1	5,0

ISO 20884:2019(E)

Table 2 (continued)

Number	Sulfur content mg/kg
2.2	10,0
2.3	25,0
2.4	50,0

Table 3 — Calibration solutions — High sulfur range

Number	Sulfur content mg/kg
Blank solution 0	0,0
3.1	50,0
3.2	100,0
3.3	200,0
3.4	350,0
3.5	500,0

8.4 Storage and stability of the calibration solutions

Calibration solutions prepared in accordance with [Table 2](#) have a limited stability and shall be used on the day they are prepared.

Calibration solutions prepared in accordance with [Table 3](#) have a stability of no more than one week if stored in a cool location (refrigerator).

9 Settings

9.1 Measuring parameters

For optimum measuring parameters, refer to [Table 1](#).

9.2 Optimization

The spectrometer shall be optimized in accordance with the manufacturer's specifications in order to achieve the optimum signal-to-noise ratio. The calibration solution with 50 mg/kg sulfur is recommended for optimization.

For polychromatic excitation, the counting time shall be set so that the total net count from a 50 mg/kg solution is $\geq 40\,000$. This counting time shall be used for both calibration (see [Clause 10](#)) and measurement (see [Clause 11](#)).

For monochromatic excitation, check the manufacturer recommendation for optimization.

9.3 Performance check of the spectrometer

Prior to a measurement series (calibration and/or measurement), but in any case, at least once daily, the manufacturer's specifications shall be used to check that the spectrometer is operating correctly, so that an optimum performance and a consistent standard of highest possible quality is ensured.

Performance checks should be carried out on a regular basis, since such checks give valuable information about the status and stability of the spectrometer.

10 Calibration

10.1 General

Ensure that the spectrometer is in an optimized condition after having executed all provisions given in [Clause 9](#) and operating optimally before calibration (see [9.3](#)).

For the range from 5 mg/kg to 60 mg/kg sulfur, and for the range 60 mg/kg to 500 mg/kg sulfur, separate calibrations shall be conducted.

10.2 Calibration solutions

Transfer the calibration solutions ([8.3](#)) into suitable sample cups so that the minimum volume is achieved (see paragraph below). Depending on the concentration range, all calibration solutions prepared in accordance with [Tables 2](#) or [3](#) shall be measured consecutively in ascending order. The count rate, I_S , of the S K-L_{2,3} X-ray fluorescence radiation at 0,537 3 nm, and the count rate, I_B , of the background radiation at 0,545 nm, shall be measured consecutively. For instruments utilizing monochromatic excitation, measurement of the background radiation is not required (see [6.1](#)).

Sample quantities that are too small give a low result or relatively more evaporation/concentration effects when measuring volatile samples, while too much sample causes more sagging of the cell window, especially when aromatic samples are measured. It is necessary to determine the minimum volume by proceeding as follows: start with 1 ml, measure the net count rate, add liquid, measure again the count rate. Repeat until the count rate remains constant for greater volumes of liquid. Plot a curve of net count rate vs volume and choose a volume greater than the point at which the curve becomes flat.

For polychromatic excitation, typically use 5 g of materials in a 28 mm sample cup or 10 g of materials in a 40 mm sample cup. For monochromatic excitation, typically use 0,8 g of materials in a 20 mm sample cup and 4 g of materials in a 42,9 mm sample cup. If in doubt, check the manufacturer recommendations.

10.3 Calibration curves

The net count rate, R_0 , is calculated according to [Formula \(1\)](#) or [\(2\)](#). To determine the calibration, the net count rate, R_0 , is plotted as a function of the corresponding sulfur content. Use the spectrometer software or a spreadsheet program to perform a regression of the data to fit to [Formula \(3\)](#).

The regression calculation may be carried out either separately or using the spectrometer calculator.

$$R_0 = I_S - I_B \text{ when background is measured, or} \quad (1)$$

$$R_0 = I_S \text{ for monochromatic excitation, when no background is measured} \quad (2)$$

$$x = a + b R_0 + c R_0^2 \quad (3)$$

where

- R_0 is the net count rate for the relevant determination;
- I_S is the count rate of the S K-L_{2,3} X-ray fluorescence radiation at 0,537 3 nm;
- I_B is the count rate of the background radiation at 0,545 nm;
- x is the sulfur content of the relevant calibration solution, expressed in milligrams per kilogram (mg/kg);
- a, b, c are the parameters from the regression calculation.

NOTE Parameter c can be zero where the calibration curve has been shown to be linear.

This is a free preview. Purchase the entire publication at the link below:

[Product Page](#)

-
- Looking for additional Standards? Visit Intertek Inform Infostore
 - Learn about LexConnect, All Jurisdictions, Standards referenced in Australian legislation
-